Remote Control

TV on/off

Power Button

Set-Top Box

View Live TV

Remote Control Unit Setup

Play

Rewind

DVR List Pulls up DVR List
Fast Forward in intrevals
Rewind in intrevals

Pause

Menu **Stop**
Settings Menu

Fast Forward

Record

Navigation Buttons

Info
Display Program Information

Guide
Display Channel Guide

OK
Navigation Select

Day Buttons
In the guide moves you a half day up or down.

Exit
Quit a function

Page Buttons
Moves the pages up and down in the guide

Work with the Hardware Settings Menu

Volume Up

Channel Up

Volume Down

Mute Button

Channel Down

***Note: While in the Guide the customer can use the channel up/down button to move the guide up/down a whole page.

These buttons are not currently used with the system.

Number Key Pad

Last
Takes you to the last channel you were on

These buttons are not currently used with the system.

CC (Close Caption)