


Norstar 3x8 Programming Instructions

Changing the Name of a Telephone

(Performing "System" Programming will make the change for all Telephone Sets.)

Programming must be performed on a M7310 or T7316 Telephone Set, Layout as follows:



Norstar Programming Overlay goes over 4 programmable keys on telephone set (middle of phone), as follows:

(If customer don't have overlay, following is what the keys will be when they enter programming below:)

(Key should be Line 1)	Heading	<input type="text"/>	<input type="text"/>	Show
(Key should be Line 2)	Back	<input type="text"/>	<input type="text"/>	Next

Press 

Enter from Key Pad **23646

Enter Password from Key Pad 23646 or ADMIN

Display Window Shows: 1. System Speed Dial Press Next

 2. Names Press Show twice

 Show Set: __ __ __ Enter 2 or 3-digit extension number you want to change the name

Press Change Memory Key under 2-Line Display Window

Enter Name (using dial pad) Use # key to space (can enter up to 7 characters)

Press  To end.

